



4G GPS SOS SMARTWATCH



USER GUIDE

Visit: www.SecuLife.us

TABLE OF CONTENTS

	CHAPTER 1	3
	QUICK SETUP GUIDE	4
READ ME	GETTING STARTED.....	5
	CHAPTER 2.....	10
READ ME	MEET YOUR DEVICE	11
	WHAT DO THE STATUS MEAN?.....	12
	CHARGING YOUR DEVICE.....	13
	ACTIVATING AN SOS ALARM	14
	MAKING A PHONE CALL	15
	SMARTWATCH SETTING	16
	CHAPTER 3:	17
	MAP PAGE	18
	NOTIFICATIONS	19
	MY DEVICES	20
	DEVICE DETAILS.....	21
	CREATE A GEO FENCE	22
	LOCATION HISTORY	23
READ ME	SET CONTACT NUMBER	24
	ENABLING ALERTS	25
	SET SOS NUMBER.....	26
	ANSWER MODE	27
	PHONEBOOK.....	28
	QUESTIONS	29
	SAFETY INFORMATION/WARNING/CAUTION	30



CHAPTER 1

AN OVERVIEW ON THE QUICK INITIAL SETUP GUIDE

**KEEP YOUR LOVED ONES SECURE AND
INDEPENDENT BOTH AT HOME AND ON THE GO.**



QUICK SETUP GUIDE

1

ACTIVATE YOUR SERVICE PLAN ONLINE
RECEIVE A NEW PHONE NUMBER FOR
YOUR SOS SMARTWATCH

2

SWITCHING DEVICE ON AND OFF
WITH A SIMPLE PRESS OF A BUTTON

3

DOWNLOAD THE MOBILE APP
TO REMOTELY MONITOR YOUR LOVED
ONE. ANYTIME. ANYWHERE!

4

LOGIN TO THE MOBILE APP
USE THE USERNAME AND PASSWORD YOU
ENTERED DURING ACTIVATION, THEN
LOGIN TO OUR APP!

5

UPDATE MOBILE APP SETTINGS
SET THE CORRECT INFO OF THE DEVICE
WEARER AND THE APP USER

1

ACTIVATE YOUR SERVICE PLAN ONLINE

YOUR SECULIFE® SOS SMARTWATCH COMES WITH A PREINSTALLED SIM CARD; THE SIM CARD NUMBER IS LOCATED ON THE BOX. ACTIVATE THE SERVICE PLAN ON YOUR SIM ONLINE AND RECEIVE A NEW PHONE NUMBER ASSOCIATED TO THE DEVICE



VISIT: WWW.ACTIVATE.SECULIFE.US

WE WILL REGISTER YOUR EMAIL ADDRESS AND LINK THE DEVICE TO OUR SECULIFE® MOBILE APP WHEN ACTIVATING YOUR DEVICE SIM CARD, SO YOU DON'T HAVE TO MANUALLY REGISTER TO THE APP. YOU'LL RECEIVE AN EMAIL CONFIRMATION WITH THE NEW NUMBER FOR YOUR RECORDS AND TO BE USED TO UPDATE YOUR MOBILE APP DEVICE INFO ON THE FOLLOWING STEPS.

2

SWITCHING DEVICE ON AND OFF

TO TURN THE DEVICE ON:

PRESS THE POWER/CLOCK BUTTON FOR **3-5 SECOND**, THE SCREEN WILL LIGHT UP AND YOU WILL HEAR RINGTONE. RAPIDLY THE DEVICE CAN ALSO BE TURNED ON AUTOMATICALLY BY CHARGING VIA MAGNETIC USB CABLE OR PUT IT INTO THE DOCKING STATION.

TO TURN THE DEVICE OFF:

- WHEN NO SIM CARD IS IN THE SOS SMARTWATCH, PRESS THE POWER BUTTON FOR **3 TO 5 SECONDS** TILL YOU HEAR A RINGTONE TO POWER IT OFF.
- WHEN A SIM CARD IS INSIDE, TO AVOID WRONG OPERATION, THE WATCH CAN BE POWERED OFF ONLY VIA APP SETTING.



IF THE SOS SMARTWATCH DOESN'T TURN ON, IT LIKELY NEEDS TO BE CHARGED. CHARGE IT FOR SEVERAL HOURS AND THEN TRY AGAIN.

3

DOWNLOAD THE MOBILE APP

TO DOWNLOAD, SCAN THE QR CODE BELOW FROM YOUR
CELLPHONE:



SECLIFE



Scan QR Code on
iOS Device



Scan QR Code on
Android Device



www.Seculife.us/ios



www.Seculife.us/android

OUR MOBILE APP IS ALSO AVAILABLE ON APPLE APP
STORE OR GOOGLE PLAY STORE. SEARCH "SECLIFE" TO
FIND THE APP.

4

LOGIN TO THE MOBILE APP

A FAMILY MEMBER OR THE CAREGIVER CAN OPEN THE MOBILE APP AND LOGIN TO THEIR ACCOUNT WITH A USERNAME AND PASSWORD THAT WAS CREATED DURING THE SIM CARD ACTIVATION PROCESS ONLINE.

- ENTER YOUR EMAIL ADDRESS AS USERNAME.
- ENTER YOUR PASSWORD.

Sign In

Enter username →

Enter Password →

SIGN IN

REGISTER

Biometric login provides a convenient method for authorizing access to your app. Instead of having to remember your username and password every time you open your app

By continuing, you agree to accept our [Privacy Policy & Terms of Service](#).


 [Use Biometrics to Sign-in](#)

5

UPDATE THE
DEVICE INFO ON
YOUR MOBILE APP

WHEN YOU FIRST ACTIVATE YOUR SOS SMARTWATCH'S SIM CARD ONLINE, THE DEVICE WILL BE ADDED INTO YOUR MOBILE APP ACCOUNT AUTOMATICALLY. YOU CAN ACTIVATE MULTIPLE DEVICES ONLINE, MAKE SURE YOU USE THE SAME EMAIL ADDRESS OF YOUR MOBILE APP IN ORDER ADD THE DEVICE UNDER YOUR MOBILE APP LOGIN ACCOUNT.

- 1. TAP ON YOUR DEVICE TO GO TO THE DEVICE DETAILS TO SET/UPDATE ITS SETTINGS.**
- 2. SET MAIN CONTACT NUMBER:** THE PERSON'S (ADMIN'S) PHONE NUMBER, CARING FOR THE SENIOR, TO RECEIVE APP ALERTS.
- 3. SET SOS NUMBER:** LIST OF PHONE NUMBERS TO RECEIVE NOTIFICATION ALERTS WHEN THE SOS BUTTON IS TRIGGERED.



DETAILED INFO OF THESE STEPS CAN BE
FOUND IN CHAPTER 3 OF THIS MANUAL.



SecuLife®

CHAPTER 2

MEET YOUR SECULIFE® SOS SMARTWATCH

A GAME-CHANGING, PERSONAL SECURITY
MONITORING SYSTEM FOR THOSE WHO MATTER
MOST IN YOUR LIFE!



MEET YOUR SOS SMARTWATCH

MEET THE SOS SMARTWATCH



SOS Button

Power & Clock Button



Charging Port

Back

Camera



Home Button









Front

HOW TO UNLOCK THE SCREEN?

PRESS THE CLOCK BUTTON TO UNLOCK SCREEN WHEN IT IS UNLOCKED, SLIDE THE SCREEN FOR FUNCTIONS YOU NEED. PRESS "HOME" KEY TO RETURN TO THE MAIN PAGE.

WHAT DO THE STATUS MEAN?

WHEN THE SCREEN IS ON, SLIDE DOWN FROM THE TOP OF THE SCREEN TO DISPLAY THE WORKING STATUS OF THE SOS SMARTWATCH. THE INSTRUCTIONS ARE AS FOLLOWS

	4G Network OK		Data needs to be set
	2G Network OK		
	No Network with a SIM card		SIM signal strength
	No SIM card or not read the SIM		Battery Status



CHARGE YOUR DEVICE

PLEASE USE THE MAGNET USB CHARGER TO CHARGE THE SOS SMARTWATCH

- CONNECT THE MAGNETIC CHARGING CABLE TO THE DEVICE AS SHOW IN PICTURE



FIRST TIME CHARGE

WHEN USING THE DEVICE FOR THE FIRST TIME, PLEASE FULLY CHARGE THE BATTERY FOR AROUND 4-6 HOURS. IN THE MEANTIME, YOU CAN ACTIVATE THE SIM CARD THAT COMES WITH THE SOS SMARTWATCH DEVICE IF YOU HAVEN'T DONE IT YET.

WHEN THE BATTERY LEVEL FALLS BELOW 20% THE DEVICE WILL SEND A LOW BATTERY WARNING MESSAGE TO RECIPIENTS ON THE CONTACT LIST VIA TEXT MESSAGE OR IN-APP NOTIFICATION.

USE ONLY THE SECU LIFE® AUTHORIZED CHARGERS



AVOID LEAVING THE MAGNETIC CABLE PORT ON METAL SURFACES TO AVOID A SHORT CIRCUIT THAT MIGHT CAUSE DAMAGE OR FIRE.

ACTIVATING AN SOS ALARM

SOS WILL IMMEDIATELY CONTACT THE EMERGENCY CONTACT LIST AND SEND AN SMS ALERT AND IN-APP ALERT.

WHEN YOU NEED HELP, PRESS THE SOS BUTTON FOR 3-5 SECONDS UNTIL YOU HEAR A VOICE PROMPT, INDICATING AN SOS ALARM. THIS STARTS THE SEQUENCE OF DIALING THE RESET SOS CONTACT NUMBER.

- IF THE DEVICE FAILS TO CONNECT TO THE FIRST NUMBER, IT WILL CALL THE SECOND NUMBER AFTER DELAY OF 10 SECONDS. IN CASE THE SECOND NUMBER FAILS TO BE CONNECTED AS WELL, THE SYSTEM WILL CONNECT TO THE THIRD NUMBER ETC.



PLEASE REMEMBER TO PROGRAM EMERGENCY CONTACT NUMBERS. IT IS NOT MANDATORY FOR ALL SOS NUMBERS TO BE SET, HOWEVER MINIMUM OF ONE MUST ALWAYS BE SET.

MAKING A PHONE CALL

CALL OUT/DIAL NUMBERS:

TO MAKE A CALL, SLIDE/SWIPE THE THE SMARTWATCH SCREEN AND FIND THE PHONE CALL INTERFACE, CLICK IN AND FIND THE STORED NUMBERS YOU NEED TO CALL, CLICK ON THE NUMBER TO MAKE A CALL.

PICK UP A CALL:

WHEN YOU RECEIVE A PHONE CALL ON YOUR SMARTWATCH, IT WILL RING AND VIBRATE. PRESS THE GREEN ICON TO PICKUP THE CALL, AND THE RED ICON TO REJECT IT

END A CALL:

TO END THE CALL, PRESS RED BUTTON ON THE SCREEN.

VOICE CHAT: THIS SERVICE IS CURRENTLY NOT AVAILABLE.



SMARTWATCH SETTING

TO ADJUST THE WATCH SETTINGS, LIKE SOUND VOLUME AND SCREEN LOCK TIME, ETC. UNLOCK YOUR SMARTWATCH, THEN SLIDE/SWIPE THROUGH THE SCREEN TO GO TO THE WATCH SETTING AND CHOOSE THE FUNCTION YOU WANT TO SET.



CHAPTER 3

MEET OUR MOBILE APP

A NEW, NEXT-LEVEL, AND EASY WAY TO PROTECT
AND CONNECT WITH YOUR LOVED ONE. ANYTIME,
ANYWHERE!



SECULIFE


MAP PAGE

MOBILE APP HOME SCREEN WILL DISPLAY THE **MAP** AND THE DEVICE(S) LAST SEEN LOCATION ON THE MAP. MOBILE APP ALSO HAVE OTHER FUNCTIONS AVAILABLE (**ADD FENCES, NOTIFICATIONS, MY DEVICES**) ON THE FUNCTION BAR TO TRACK, LOCATE AND SETUP THE SOS TRACKERS AT YOUR CONVENIENT.

CLICK TO SEE
DEVICE NAME

YOU CAN CLICK ON THE DEVICE TO SEE THE DEVICE NAME, BATTERY LEVEL & TRACKING INTERVALS. THE NAME CAN BE CHANGED FROM MY DEVICES PAGE.

YOU CAN SEE ALL OF YOUR DEVICES ON YOUR MAP, IF YOU HAVE MORE THAN A DEVICE ADDED TO YOUR MOBILE APP,





NOTIFICATIONS

SEE ALL THE NOTIFICATION RECEIVED FROM YOUR DEVICE

SEE THE ALERT TYPE AND THE DEVICE NAME WITH THE DATE & TIME OF THE ALERT.

IF YOU HAVE MULTIPLE DEVICES ADDED TO YOUR MOBILE APP, YOU WILL SEE ALL THE NOTIFICATIONS FOR ALL OF YOUR DEVICES FROM THIS NOTIFICATION PAGE. TO SEE THE NOTIFICATIONS OF A SPECIFIC DEVICE ONLY, YOU CAN GO TO: **MY DEVICES >> SELECT A DEVICE >> NOTIFICATIONS BUTTON ON THAT PAGE.**

Notifications	
Fence Notification	11/09/2021 16:03
Device Susan is out of fence DR's Fence	
Fence Notification	11/09/2021 14:17
Device Susan is back to fence DR's Fence	
Fence Notification	11/08/2021 12:22
Battery Low Alert from Susan	
Fence Notification	11/04/2021 18:34
Device Susan is back to fence Home	
Fence Notification	11/04/2021 14:58
SOS Alert from Susan	
Fence Notification	11/04/2021 14:48
SOS Alert from Susan	
Fence Notification	11/03/2021 16:31
Device Susan is out of fence Park Fence	
Fence Notification	11/03/2021 16:03
Device Susan is back to fence Park Fence	
Fence Notification	11/02/2021 14:55
Device Susan is out of fence Home	



Settings

MY DEVICES

FROM YOUR MOBILE APP HOME SCREEN, TAP ON "MY DEVICES" TO SEE LIST OF DEVICES, IF YOU HAVE MULTIPLE DEVICES. CLICK ON THE DEVICE TO GO TO THE "DEVICE DETAILS".

Click on + to Add a new Device


From **My Devices** page you will see

- Device Name (The name can be changed from Device Details)
- Battery level
- Device SIM card and IMEI #
- Last seen date/time.

Click on a device to go to "**Device Details**" to setup and update the device information at anytime.

*Device status Types

- Online: This is when Device status indicates its online and connected to the App.
- Offline: This is when the device is switched off or ran out of battery or no network signal is detected.



Click "My Devices" to see your device list



Settings

DEVICE DETAILS

FROM YOUR MOBILE APP HOME SCREEN, TAP ON "MY DEVICES" THEN CLICK ON THE DESIRED DEVICE TO ACCESS AND TO GO TO ITS "DEVICE DETAILS". NOTIFICATIONS | HISTORY | SETTINGS WILL BE EXPLAINED ON THE FOLLOWING PAGES ON THIS CHAPTER

GEO FENCES:


SELECT THE DESIRED GEO-FENCE (SUCH AS HOME, SCHOOL, PARK... ETC.) TO RECEIVE ALERTS WHEN THE DEVICE ENTERS OR LEAVES THESE AREAS.

WIFI FENCE:

RECEIVE ALERTS WHEN THE DEVICE ENTERS OR LEAVES A WIFI RANGE OF A SELECTED WIFI NETWORK.

TRACKING INTERVAL:

SET UP LOCATION UPLOAD INTERVALS. THIS IS HOW OFTEN DO YOU WISH THE DEVICE TO REPORT THE LOCATION, WE SUGGEST TO SETUP TO 12 HOURS TO ENHANCE BATTERY-SAVING MODE; THIS WILL ENSURE THE DEVICE HAS SUFFICIENT BATTERY POWER FOR ANY POTENTIAL SOS ALERTS.



GEO-FENCE

GEO FENCING, ALSO KNOWN AS "SAFE ZONES," CAN BE SET UP FROM THE MOBILE APP; YOU CAN ADD, EDIT OR REMOVE A GEO-FENCE AREA. ONCE A GEO FENCE IS CREATED YOU CAN SELECT THE FENCE(S), FROM DEVICE DETAILS PAGE, TO RECEIVE ALERTS WHEN ENTERING OR EXITING A GEO-FENCE AREA.

ADD GEO FENCE:

- CLICK ON **NEW FENCE** BUTTON FIRST THEN SET A PERIMETER ON THE MAP
- CLICK ON **SAVE** BUTTON AND ENTER THE FENCE NAME (SUCH AS HOME, DOCTOR'S OFFICE, PARK... ETC.).


RECOMMENDED GPS RADIUS OF 1000 FEET OR HIGHER TO REDUCE FALSE ALERTS.

YOU CAN SETUP MULTIPLE GEO FENCE LOCATIONS AS NEEDED.

DELETE GEO FENCE:

- TO DELETE A GEO FENCE, CLICK ON THE DESIRED FENCE FIRST, THEN CLICK ON **DELETE** BUTTON


CLICK TO ADD OR DELETE FENCES



LOCATION HISTORY

THE HISTORICAL ROUTE, ALSO KNOWN AS LOCATION HISTORY, WILL DISPLAY THE HISTORICAL ROUTE OF ANY DAY/TIME WITHIN THE PAST 365 DAYS. TO HELP YOU SEE THE PRESENT AND PAST PLACES VISITED.

SELECT A DATE & TIME TO SEE THE TRACKING HISTORY.



CLICK ON ANY OF THE PINPOINTS TO VIEW THE TIMESTAMP OF THE TRACKED EVENT.

ADMIN

SET CONTACT INFO

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS" THEN FILL UP
THE "SMS ALERTS PHONE#"

& "ALERTS E-MAIL" TO RECEIVE THE
NOTIFICATION ALERTS (LIKE THE SOS
ALERTS AND, ENTERING/EXITING GEO-
FENCE AREAS, LOW BATTERY ALERTS,
ETC).

← Settings

Victor's SOS watch

Time Zone:
Pacific

SOS Alerts:
[Email, Notification, SMS]

Battery Alerts:
[Email, Notification, SMS]

Removal Alerts:
[]

Geo-Fence Alerts:
[Email, Notification, SMS]

Fall Down Alerts:
[]

SOS Phone#:
[]
[]
[]

SMS Alerts Phone#
[]

Alerts E-Mail:
[]

SMS ALERTS PHONE:

THE PERSON'S PHONE NUMBER WHO
WILL BE RECEIVING ALERTS FORM THE
DEVICE.

ALERTS E-MAIL:

THE PERSON'S EMAIL ADDRESS WHO
WILL BE RECEIVING EMAIL ALERTS
FORM THE DEVICE.

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "UPDATE" BUTTON



ENABLING ALERTS

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
 SELECT YOUR DEVICE, CLICK ON "SETTINGS". YOU WILL
 SEE THE OPTIONS TO CHOOSE YOUR ALERTS OPTIONS.

ENABLE THESE ALERTS TO SET
 THE DEVICE TO SEND
 SMS/EMAIL/IN-APP NOTIFICATION
 ALERTS TO THE PHONE# & EMAIL
 YOU'VE SET (MONITORING)
 PERSONNEL AND RECEIVE IN-APP
 NOTIFICATIONS

SOS ALERTS:
 CHOOSE HOW YOU WISH TO
 RECEIVE YOUR ALERTS (EMAIL, SMS
 OR IN-APP NOTIFICATION) IN THE
 EVENT OF SOS BUTTON IS
 ACTIVATED

BATTERY ALERTS:
 SELECT THE DESIRED NOTIFICATION
 OPTION RECEIVED WHEN BATTERY
 LEVEL IS LOW.

GEO-FENCE ALERTS:
 CHOOSE HOW YOU WISH TO
 RECEIVE YOUR ALERTS (EMAIL, SMS
 OR IN-APP NOTIFICATION)
 EVERYTIME THE DEVICE ENTERS OR
 LEAVES THE GEO FENCE AREA



UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
 ON THE "UPDATE" BUTTON

SET SOS NUMBER

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS" THEN "SOS
PHONE #"

SET SOS PHONE NUMBER:

LIST OF THE PHONE NUMBER(S) TO RECEIVE NOTIFICATION SMS AND CALLS WHEN THE SOS BUTTON IS TRIGGERED.
YOU CAN SET UP-TO 3 PHONE NUMBERS.

PLEASE REMEMBER TO PROGRAM EMERGENCY CONTACT NUMBERS. IT IS NOT MANDATORY FOR ALL THREE AUTHORIZED NUMBERS TO BE SET, HOWEVER A MINIMUM OF ONE MUST ALWAYS BE SET. ALSO DON'T FORGET TO SET THE SOS ALERT TO SET THE WAY YOU WANT THE SOS ALERTS TO BE RECEIVED.

← Settings

Victor's SOS watch

Time Zone:
Pacific

SOS Alerts:
[Email, Notification, SMS]

Battery Alerts:
[Email, Notification, SMS]

Removal Alerts:
[]

Geo-Fence Alerts:
[Email, Notification, SMS]

Fall Down Alerts:
[]

SOS Phone#:
[]
[]
[]

SMS Alerts Phone#
[]

Alerts E-Mail:
[]

DO NOT LIST 911 AS A PHONE NUMBER IN THE SOS PHONE# LIST

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING ON THE "UPDATE" BUTTON

ANSWER MODE

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES SELECT YOUR DEVICE, CLICK ON "SETTINGS". TO CHOOSE HOW YOU WISH THE DEVICE TO ANSWER AN INCOMING PHONE CALL.

- **PRESS TO ANSWER:** ALLOW YOUR LOVED ONE TO ANSWER A CALL AT THE COMFORT OF THEIR DEVICE WITH ONE TOUCH OF THE ANSWER CALL BUTTON FROM THEIR SOS TRACKER DEVICE.
- **HANDS-FREE AUTO-ANSWER:** AUTO PICK-UP SPEAKERPHONE TO SPEAK TO YOUR LOVED ONE ANYTIME AND INSTANTLY KNOW WHEN YOUR LOVED ONE NEEDS YOU.

← Settings

[Email]

SOS Phone#:

SMS Alerts Phone#

Alerts E-Mail:

Answering Mode: Press Button to Answer Auto Answer

Phone Book:

Phone Book #1	Phone Book #6
Phone Book #2	Phone Book #7
Phone Book #3	Phone Book #8
Phone Book #4	Phone Book #9
Phone Book #5	Phone Book #10

UPDATE

Home QR Bell My Devices

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING ON THE "UPDATE" BUTTON

PHONE BOOK

FROM YOUR MOBILE APP HOME SCREEN, TAP ON DEVICES
SELECT YOUR DEVICE, CLICK ON "SETTINGS" THEN "**PHONE BOOK**"

LIMIT YOUR LOVED ONE'S CONTACTS TO ONLY KNOWN
FAMILY OR FRIENDS, AND THE MAIN PERSON CARING FOR
THE SENIOR **MUST BE SET AS THE PRIMARY CONTACT
PHONE NUMBER.**

SAVE THE PHONE NUMBERS OF THE
FAMILY/FRIENDS.

ONLY NUMBERS IN THE PHONE BOOK
CAN GET THROUGH THE CALLS TO SOS
TRACKER, NUMBERS NOT LISTED HERE
WILL NOT BE ABLE TO CALL THE
NUMBER ASSIGNED TO THE DEVICE.

← Settings

[Email]

SOS Phone#:

SMS Alerts Phone#

Alerts E-Mail:

Answering Mode: Press Button to Answer Auto Answer

Phone Book:

Phone Book #1	Phone Book #6
Phone Book #2	Phone Book #7
Phone Book #3	Phone Book #8
Phone Book #4	Phone Book #9
Phone Book #5	Phone Book #10

UPDATE

MAKE SURE TO SCROLL DOWN AND SAVE THE CHANGES BY CLICKING
ON THE "**UPDATE**" BUTTON

SecuLife®



QUESTIONS?



CALL US
877-606-8080



CONTACT US
WWW.SUPPORT.SECULIFE.US



WATCH VIDEOS
WWW.SECULIFE.US

SAFETY INFORMATION

TO PREVENT INJURY TO YOURSELF AND OTHERS, OR TO AVOID DAMAGE TO THE DEVICE, FIRST READ ALL SAFETY INFORMATION BEFORE USE.

WARNING

- USE MANUFACTURER-APPROVED ACCESSORIES AND SUPPLIES.
- CAUTION – ELECTRICAL OPERATED PRODUCT
- THIS PRODUCT IS NOT A TOY. KEEP OUT OF REACH OF CHILDREN AND PETS UNLESS PROPERLY SUPERVISED. THE PRODUCT CONTAINS SMALL PARTS THAT CAN BE A CHOKING HAZARD.
- DO NOT DROP OR CAUSE AN IMPACT TO THE DEVICE.
- PREVENT THE CHARGING JACK AND CORD FROM COMING INTO CONTACT WITH CONDUCTIVE MATERIALS SUCH AS LIQUIDS, DUST, METALS, PENCIL LEAD, OR AEROSOLS.
- DO NOT STORE YOUR DEVICE IN EXTREMELY HOT OR IN EXTREMELY COLD AREA. RECOMMENDED TO USE YOUR DEVICE FROM 41F TO 95F
- DO NOT STORE YOUR DEVICE NEAR OR ON TOP OF HEATERS, MICROWAVES, HOT COOKING EQUIPMENT, OR HIGH-PRESSURE CONTAINERS.
- DO NOT USE YOUR DEVICE WHILE CHARGING OR TOUCH WITH WET HANDS.
- THE DEVICE AND USB CABLE SHOULD BE PERIODICALLY EXAMINED FOR BREAKS, CRACKS, OR FRAYING, WHICH COULD RISK FIRE, ELECTRICAL SHOCK, OR PERSONAL INJURY. IF

DAMAGED, THE USB CABLE SHOULD BE REPLACED OR REPAIRED BEFORE USE.

- KEEP OUT OF REACH OF CHILDREN AND PETS; SMALL PARTS ARE A CHOKING HAZARD.

CAUTION

- DO NOT DISASSEMBLE, MODIFY, OR REPAIR THE UNIT.
- ANY CHANGES OR MODIFICATIONS TO YOUR DEVICE CAN VOID YOUR MANUFACTURER'S WARRANTY. IF YOUR DEVICE NEEDS SERVICING, CONTACT CUSTOMER SUPPORT.
- DO NOT DISASSEMBLE OR PUNCTURE THE BATTERY, AS THIS CAN CAUSE EXPLOSION OR FIRE.
- DO NOT PAINT OR PUT STICKERS ON YOUR DEVICE. PAINT AND STICKERS CAN CLOG MOVING PARTS AND PREVENT PROPER OPERATION.
- IF YOU ARE ALLERGIC TO PARTS OF THE DEVICE, YOU MAY EXPERIENCE ITCHING, ECZEMA, OR SWELLING OF THE SKIN. WHEN THIS HAPPENS, STOP USING THE DEVICE AND CONSULT YOUR PHYSICIAN.
- ALLOWING UNQUALIFIED PERSONNEL TO SERVICE YOUR DEVICE MAY RESULT IN DAMAGE AND WILL VOID YOUR MANUFACTURER'S WARRANTY.



FOR WARNINGS AND DISCLAIMERS, PLEASE VISIT OUR WEBSITE