



# Kids Smart Watch



**MODEL M**

**User Guide**





## What's Included

<b>Watch</b>	<b>1</b>
<b>USB Cable</b>	<b>1</b>
<b>Instruction</b>	<b>1</b>
<b>Built-in SIM</b>	<b>1</b>



## Specifications

**Charging Volt:** 5V

**Working Temperature:** -20°C-60°C

**Networks Supported:** 4G LTE

**Band Material:** Silica Gel

**Case Material:** Plastic

**Water & Dust Proof:** Rated IP67





## Meet Your Smartwatch





**Activate Your Service Online**

**VISIT OUR WEBSITE**

[activate.seculife.us/](https://activate.seculife.us/)



Your child's Smartwatch comes with a pre-installed SIM card, which is located on the box. Activate your SIM service plan online and receive a New phone number associated with your smartwatch.

**Now you have a phone number assigned to the SIM card.**

**You may turn ON the watch.**



**Download CarePro+ Mobile App**



**The Mobile App is available on Apple App Store or Google Play Store. Search "CarePro+" to find the app.**



## Register the Smartwatch

When the installation is completed, begin the registration of your personal account on the mobile app.

**Enter your email address**

**Register Code:** ID number or register code, this is not IMEI number

**User Alias:** Child's name

**Password:** set a password

**APP Language:** English

**Region:** North America

Register

Please input your email

Please enter verification code SHWJMLC

Please enter the password of 8-16 letters + numbers com

Confirm Registration

I have read and agreed the [User Agreement](#) [Privacy Policy](#)

Language: English

Region: North America





## Login to the Mobile App

After registration is completed log into your account.

A screenshot of the mobile app's login screen. The background is light blue with a map and clouds at the bottom. At the top, it says "CONNECTING WORLD" in white, bold letters. Below that, there are links for "Forgot Password?" and "Register". There are two input fields: "Account:" and "Password: .....". Below the password field is a radio button for "Auto Login". A yellow "LOGIN" button is highlighted with a red border. At the bottom, there is a checkbox for "I have read and agreed the [User Agreement](#) [Privacy Policy](#)". Below this, there are two dropdown menus: "Language: English" and "Region: North America". A large yellow arrow points to the "Region" dropdown, which is also highlighted with a red border.

1) Enter Your Email and Password

2) APP Language: English

3) Region: North America

4) Accept Terms & Conditions by Clicking & Accepting Where Indicated.




## Setting up the watch on Mobile App

Log in, find the setting, click the phone book or contacts, and save the needed numbers. The same steps apply to the other functions.

### Set the SOS Number: (Mom / Dad / Family / Friends)

Only the phone numbers saved in the app phone book contacts can call the watch.

Remember to always click the **save** button.






## Calling Feature

### A. Calling the Kids Smartwatch:

- 1) Use your finger to slide the screen from the left or right side to find the phone book interface, click it, see phone numbers saved by the APP, and choose the number you wish to call.
- 2) Long-Press button 1. It will automatically call 3 SOS numbers one by one until it is answered. If the call is not answered, it will cycle through again.
- 3) Short Press button 1 to cancel the call.

### B. Call the Watch:


- 1) To call your child's smartwatch, press button number 2.
- 2) To receive a call or to cancel or hang up a call, press button number 1.



A decorative graphic consisting of several overlapping, semi-transparent circles in shades of purple, green, and blue.

## Create a Geo-Fence

Geo fencing, also known as "safe zones," can be set up from the mobile app: you can add, edit or remove a Geo-Fence area. You will receive alerts when entering or exiting a Geo-Fence area.



### Create Geo-fence Safezone

Tap On The Map To Set A Zone

Adjust The Size

Name The Zone

### Notes:

Recommended GPS radius of 1000 feet or higher to reduce false alerts.

You can setup multiple Geo-Fence locations as needed.

## Tracking Feature

- 1) Turn on the watch and ensure it has a signal.
- 2) Open the map on the mobile APP, click the location, and then it will show your child's location on the live map.



### Notes:

If the watch is indoors, it usually will position itself via LBS or WIFI, a slight deviation is possible; this depends on the distance between the watch, the Network Towers Base Station, and the type of building structure.



## FAQ:

If you have saved the phone numbers and the watch indicates that the device can not connect to the network.

1) Is there a signal after inserting the card?  
Please check if the watch rings when receiving a phone call.

2) Check whether the watch is on or not.  
(Note: before using the APP, the watch must be on)

3) Check whether the watch ID matches the ID on the tags.

5) If it is still not working, please get in touch with our support team online



- When you call the watch, it alerts you that the number you have dialed is busy; please try again later.

1) Is there any signal after inserting the card?

2) Please check that you have saved phone numbers on the Mobile App.

3) Check If you have turned on the DO NOT DISTURB in the App and set a time; if yes, please switch to OFF.

- **The positioning function is not working.**

1) Go outside with the watch and try again.  
(This is for GPS functions only)

2) Once the watch goes into SLEEP MODE, it will switch to SAVE POWER MODE, which means the function of uploading data is OFF.

You can refresh the position by shaking the watch to wake it up.

**SUPPORT**

Visit: [support.seculife.us](https://support.seculife.us)

**Call: 877-606-8080**



**CONTACT  
US**

## SAFETY INFORMATION

TO PREVENT INJURY TO YOURSELF AND OTHERS, OR TO AVOID DAMAGE TO THE DEVICE, FIRST READ ALL SAFETY INFORMATION BEFORE USE.

### WARNING

- USE MANUFACTURER-APPROVED ACCESSORIES AND SUPPLIES.
- CAUTION – ELECTRICAL OPERATED PRODUCT
- THIS PRODUCT IS NOT A TOY. KEEP OUT OF REACH OF CHILDREN AND PETS UNLESS PROPERLY SUPERVISED. THE PRODUCT CONTAINS SMALL PARTS THAT CAN BE A CHOKING HAZARD.
- DO NOT DROP OR CAUSE AN IMPACT TO THE DEVICE.
- PREVENT THE CHARGING JACK AND CORD FROM COMING INTO CONTACT WITH CONDUCTIVE MATERIALS SUCH AS LIQUIDS, DUST, METALS, PENCIL LEAD, OR AEROSOLS.
- DO NOT STORE YOUR DEVICE IN EXTREMELY HOT OR IN EXTREMELY COLD AREA. RECOMMENDED TO USE YOUR DEVICE FROM 41F TO 95F
- DO NOT STORE YOUR DEVICE NEAR OR ON TOP OF HEATERS, MICROWAVES, HOT COOKING EQUIPMENT, OR HIGH-PRESSURE CONTAINERS.
- DO NOT USE YOUR DEVICE WHILE CHARGING OR TOUCH WITH WET HANDS.
- THE DEVICE AND USB CABLE SHOULD BE PERIODICALLY EXAMINED FOR BREAKS, CRACKS, OR FRAYING, WHICH COULD RISK FIRE, ELECTRICAL SHOCK, OR PERSONAL INJURY. IF

- DAMAGED, THE USB CABLE SHOULD BE REPLACED OR REPAIRED BEFORE USE.
- KEEP OUT OF REACH OF CHILDREN AND PETS; SMALL PARTS ARE A CHOKING HAZARD.

### CAUTION

- DO NOT DISASSEMBLE, MODIFY, OR REPAIR THE UNIT.
- ANY CHANGES OR MODIFICATIONS TO YOUR DEVICE CAN VOID YOUR MANUFACTURER'S WARRANTY. IF YOUR DEVICE NEEDS SERVICING, CONTACT CUSTOMER SUPPORT.
- DO NOT DISASSEMBLE OR PUNCTURE THE BATTERY, AS THIS CAN CAUSE EXPLOSION OR FIRE.
- DO NOT PAINT OR PUT STICKERS ON YOUR DEVICE. PAINT AND STICKERS CAN CLOG MOVING PARTS AND PREVENT PROPER OPERATION.
- IF YOU ARE ALLERGIC TO PARTS OF THE DEVICE, YOU MAY EXPERIENCE ITCHING, ECZEMA, OR SWELLING OF THE SKIN. WHEN THIS HAPPENS, STOP USING THE DEVICE AND CONSULT YOUR PHYSICIAN.
- ALLOWING UNQUALIFIED PERSONNEL TO SERVICE YOUR DEVICE MAY RESULT IN DAMAGE AND WILL VOID YOUR MANUFACTURER'S WARRANTY.

